

## 碍子・ソケット









品番	定格	結線方法	価格(@)	
E12-01	1A 300V	ネジ止め		

番 定格 結線方法 価格(@) E17-13 3A 300V ネジ止め

品 番 定格 結線方法 価格(@) **E26-17** 6A 300V ネジ止め

品 番 定格 結線方法 価格(@) **E26-18** 6A 300V ネジ止め

### E26並台A式ソケット



品	番	定	格	結線方法	価	格	(@)
F26-22		6A 3	NOON	ネジ止め			

### E26小モーガルソケット(1ッ穴)




品	番	定	格	結線方法	価	格	(@)
E26-01		6A 3	800V	ネジ止め			

### E39大モーガルソケット



品	番	定	格	結線方法	価	格	(@)
E39-01		15A 3	300V	ネジ止め			










## E11ハロゲンソケット







番 定格 結線方法 価格(@) E11-04 7A 300V

# ●防水パッキン(シリコンゴム製) — 完全防水でなく、防滴パッキンです・

E39用

### E17用(上部電球側)



E17-PU (@)

E17用(下部電線側)



E17-PD (@)

E26用(上部電球側)



E26-PU (@)

### E26用(下部電線側)





E39用(上部電球側)



(下部電線側)

E39-PD (@)

## 碍子・ソケット(アダプター)

























